# SPARE PARTS EXPLODED VIEW
# GAS WALL BOILERS


Model

## UNOBLOC G 24/31/38/45


R8215595-02EN - Edition 02 - 01/02/2011




| Reference | Ind. | Model type | Begin | End |
|---|---|---|---|---|
| 330 0017 | | UNOBLOC GPV 24 RI MET | ... | ... |
| 330 0018 | | UNOBLOC GPV 31 RI MET | ... | ... |
| 330 0019 | | UNOBLOC G 38 RI MET | ... | ... |
| 330 0020 | | UNOBLOC G 45 RI MET | ... | ... |


112
109
138
104
503
106
535
107
108
126
150
102
103
101
106
113
503
535
105
118
119
120
114
151
117
116
111
110
115

| Key N | Description | Manf. Pt. N | Type | 24 | 31 | 38 | 45 | Manf. date from | Manf. date to |
|---|---|---|---|---|---|---|---|---|---|
| **0100** | **SEALED CASE** | | | | | | | | |
| 0101 | SIDE ELEMENT (L.H.) | 65102602 | | • | • | • | • | | |
| 0102 | INTERMEDIATE ELEMENT | 65102603 | | • | • | • | • | | |
| 0103 | SIDE ELEMENT (R.H.) | 65102604 | | • | • | • | • | | |
| 0104 | BICONIC UNION | 997318 | | • | • | • | • | | |
| 0105 | BOILER INSULATION | 65102613 | | | • | | | | |
| | BOILER INSULATION | 65102619 | | • | | | | | |
| | BOILER INSULATION | 65102672 | | | | • | | | |
| | BOILER INSULATION | 65102689 | | | | | • | | |
| 0106 | PROBES HOLDER PLUG | 65102607 | | • | • | • | • | | |
| 0107 | EXTENSION M-F | 65102609 | | • | • | • | • | | |
| 0108 | DRAIN COCK | 997390 | | • | • | • | • | | |
| 0109 | COLLAR | 65102614 | | • | • | | | | |
| 0110 | ELECTRODE (IGNITION) | 65102626 | | • | • | • | • | | |
| 0111 | ELECTRODE (DETECTION) | 65102636 | | • | • | • | • | | |
| 0112 | FLUE HOOD INSULATION | 65102612 | | | • | | | | |
| | FLUE HOOD INSULATION | 65102617 | | • | | | | | |
| | FLUE HOOD INSULATION | 65102671 | | | | • | | | |
| | FLUE HOOD INSULATION | 65102688 | | | | | • | | |
| 0113 | CONDENSER | 65102601 | | | • | | | | |
| | CONDENSER | 65102605 | | • | | | | | |
| | CONDENSER | 65102668 | | | | • | | | |
| | CONDENSER | 65102685 | | | | | • | | |
| 0114 | INTAKE (PRESSURE) | 997347 | | • | • | • | • | | |
| 0115 | SHIELDING (IGNITION ELECTRODE) | 999866 | | • | • | • | • | | |
| 0116 | ELECTRODE HOLDER PLATE | 65102634 | | • | • | • | • | | |
| 0117 | GAS MANIFOLD | 65102623 | | | • | | | | |
| | GAS MANIFOLD | 65102625 | | • | | | | | |
| | GAS MANIFOLD | 65102676 | | | | • | | | |
| | GAS MANIFOLD | 65102690 | | | | | • | | |
| 0118 | PIPE (BURNER) | 65102635 | | • | • | • | • | | |
| 0119 | GAS MANIFOLD INSULATION | 65102628 | | | • | | | | |
| | GAS MANIFOLD INSULATION | 65102637 | | • | | | | | |
| | GAS MANIFOLD INSULATION | 65102675 | | | | • | | | |
| | GAS MANIFOLD INSULATION | 65102692 | | | | | • | | |
| 0120 | GASKET | 997410 | | • | • | • | • | | |
| 0126 | INSULATING PANEL | 65102606 | | • | | | | | |
| | INSULATING PANEL | 65102608 | | | • | | | | |
| | INSULATING PANEL | 65102669 | | | | • | | | |
| | INSULATING PANEL | 65102686 | | | | | • | | |
| 0138 | FLUE HOOD | 65102610 | | • | | | | | |
| | FLUE HOOD | 65102611 | | | • | | | | |
| | FLUE HOOD | 65102670 | | | | • | | | |
| | FLUE HOOD | 65102687 | | | | | • | | |
| 0150 | GASKET | 997405 | | • | • | • | • | | |
| 0151 | PILOT HOLE COVER | 997432 | | • | • | • | • | | |



302
345
301
315
418
G
301
405
403
406
401
444
342
405
344

| Key N | Description | Manf. Pt. N | Type | 24 | 31 | 38 | 45 | Manf. date from | Manf. date to |
|---|---|---|---|---|---|---|---|---|---|
| **0300** | **CHASSIS-FRONT CASE** | | | | | | | | |
| 0301 | RODS | 65102663 | | • | • | • | • | | |
| 0302 | CASE (COVER) | 65102666 | | • | • | | | | |
| | CASE (COVER) | 65102683 | | | | • | • | | |
| 0315 | CASE PANEL (REAR) | 65102621 | | | • | | | | |
| | CASE PANEL (REAR) | 65102624 | | • | | | | | |
| | CASE PANEL (REAR) | 65102679 | | | | • | | | |
| | CASE PANEL (REAR) | 65102693 | | | | | • | | |
| 0342 | CASE PANEL (L.H. SIDE) | 65102639 | | • | • | • | • | | |
| 0344 | PANEL (FRONT CASE) | 65102667 | | • | • | | | | |
| | PANEL (FRONT CASE) | 65102684 | | | | • | • | | |
| 0345 | CASE PANEL (R.H. SIDE) | 65102638 | | • | • | • | • | | |
| | | | | | | | | | |
| **0400** | **GAS SECTION** | | | | | | | | |
| 0401 | GAS ELECTROVALVE | 997343 | | • | • | • | • | | |
| 0403 | GAS FLANGE | 997357 | | • | • | • | • | | |
| 0405 | GASKET | 997410 | | • | • | • | • | | |
| 0406 | GASKET | 997411 | | • | • | • | • | | |
| 0418 | GAS INLET PIPE | 65102630 | | • | • | • | • | | |
| 0444 | PRINTED CIRCUIT BOARD (FLAME CONTROL) | 997354 | | • | • | • | • | | |



503
533
571
537
113
574
505
538
113
535

| Key N | Description | Manf. Pt. N | Type | 24 | 31 | 38 | 45 | Manf. date from | Manf. date to |
|---|---|---|---|---|---|---|---|---|---|
| **0500** | **WATER SECTION ASSY** | | | | | | | | |
| 0503 | PIPE (C.H. FLOW) | 65102615 | | • | • | | | | |
| | PIPE (C.H. FLOW) | 65102673 | | | | • | • | | |
| 0505 | EXPANSION VESSEL | 65102622 | | • | • | | | | |
| 0533 | PIPE (C.H. RETURN) | 65102616 | | • | • | | | | |
| | PIPE (C.H. RETURN) | 65102674 | | | | • | • | | |
| 0535 | PIPE (C.H. RETURN) | 65102618 | | • | • | | | | |
| 0537 | SAFETY VALVE | 997377 | | • | • | | | | |
| 0538 | KIT FOR VERTICAL 1 PUMP ATTACHMENTS | 996617 | | • | • | | | | |
| 0571 | PRESSURE SWITCH | 65070762 | | • | • | | | | |
| 0574 | GASKET | 997407 | | • | • | • | • | | |

## 600


620
601
646
615
612
613
616
617
610
607
608
618
611
609
624
606
637
614
605
604
602
640
633
603
619

## 5000


5001
NAT > B/P
5002
B/P > NAT
5003
> GZ350-G27
5004

| Key N | Description | Manf. Pt. N | Type | 24 | 31 | 38 | 45 | | Manf. date from | Manf. date to |
|---|---|---|---|---|---|---|---|---|---|---|
| **0600** | **ELECTRICAL BOX** | | | | | | | | | |
| 0601 | ELECTRIC PANEL (COMPLETE) | 65102640 | | • | • | | | | | |
| | ELECTRIC PANEL (COMPLETE) | 65102680 | | | | • | • | | | |
| 0602 | THERMOMETER | 65102659 | | • | • | • | • | | | 07/00 |
| | THERMOMETER | 999807 | | • | • | • | • | | 08/00 | |
| 0603 | PLUG | 65102645 | | • | • | • | • | | | |
| 0604 | BUTTON | 65102646 | | • | • | • | • | | | |
| 0605 | SIGNAL LAMP CAP (GREEN) | 65102650 | | • | • | • | • | | | |
| 0606 | SIGNAL LAMP CAP (RED) | 65102682 | | • | • | • | • | | | |
| 0607 | SIGNAL LAMP | 65102652 | | • | • | • | • | | | |
| 0608 | SIGNAL LAMP | 65102653 | | • | • | • | • | | | |
| 0609 | SWITCH | 65102654 | | • | • | • | • | | | |
| 0610 | BIPOLAR SWITCH | 65102655 | | • | • | • | • | | | |
| 0611 | SWITCH | 65102656 | | • | • | • | • | | | |
| 0612 | FUSES HOLDER | 65102657 | | • | • | • | • | | | |
| 0613 | CONTROL PANEL FRAME | 65102648 | | • | • | • | • | | | |
| 0614 | CONTROL PANEL | 65102641 | | • | • | | | | | |
| | CONTROL PANEL | 65102681 | | | | • | • | | | |
| 0615 | FUSE | 65102658 | | • | • | • | • | | | |
| 0616 | THERMOSTAT (SAFETY) | 65102660 | | • | • | • | • | | | |
| 0617 | THERMOSTAT (FLUE SAFETY) | 997429 | | • | • | • | • | | | |
| 0618 | THERMOSTAT (REGULATION) | 65102662 | | • | • | • | • | | | |
| 0619 | ELECTRIC BOX COVER | 65102664 | | • | • | • | • | | | |
| 0620 | SERVICE COVER | 65102665 | | • | • | • | • | | | |
| 0624 | PUSH-PUSH | 65102647 | | • | • | • | • | | | |
| 0633 | CONTROL KNOB | 65102643 | | • | • | • | • | | | |
| 0637 | COVER (THERMOSTAT REGULATION) | 65102642 | | • | • | • | • | | | |
| 0640 | PUSH BUTTON | 65102644 | | • | • | • | • | | | |
| 0646 | COMPLETE WIRING (ELECTRIC PANEL) | 65102649 | | • | • | • | • | | | |
| | | | | | | | | | | |
| **5000** | **ACCESSORY** | | | | | | | | | |
| 5001 | LPG BURNER JET FULL KIT | 65102976 | | • | • | | | | | |
| | LPG BURNER JET FULL KIT | 65102977 | | | | • | • | | | |
| 5002 | NATURAL GAS BURNER JET FULL KIT | 65102627 | | • | | | | | | |
| | NATURAL GAS BURNER JET FULL KIT | 65102629 | | | • | | | | | |
| | NATURAL GAS BURNER JET FULL KIT | 65102678 | | | | • | | | | |
| | NATURAL GAS BURNER JET FULL KIT | 65102691 | | | | | • | | | |
| 5003 | GZ350-G27 GAS BURNER JET FULL KIT | 65102979 | | • | • | | | | | |
| | GZ350-G27 GAS BURNER JET FULL KIT | 65102980 | | | | • | • | | | |
| 5004 | INTERMITTENT PILOT (KIT) | 65102982 | | • | • | • | • | | | |

# LIST OF THE ABBREVATIONS

| | |
|---|---|
| **HW** ..... | **: Hot water.** |
| **CW** ..... | **: Cold water.** |
| **C** ..... | **: Ceramic resistance (normal heating).** |
| **Ca** ..... | **: Ceramic resistance (accelerated heating)** |
| **TP** ..... | **: Immersion heater.** |
| **1F** ..... | **: With fittings.** |
| **2F** ..... | **: Without fittings.** |
| **3F** ..... | **: With fittings and another outlet connection.** |
| **AMI** ..... | **: With mixing valve.** |
| **SMI** ..... | **: Without mixing valve.** |
| **PUISS** ..... | **: Power of th appliance.** |
| **PN** ..... | **: Appliance with normal pression.** |
| **LP** ..... | **: Appliance with low pression.** |
| **PV** ..... | **: Appliance with variable power.** |
| **PF** ..... | **: Appliance with fixed power..** |

# IDENTIFICATION PLATE

**SERIAL NUMBER**

**11 Characters :** 1 95 065004 - 31

- Month of manucfacture : from 1 to 9 ➟ Jan. to Sep., O ➟ Oct., N ➟ Nov., D ➟ Dec.
- Technical number of the appliance
- Sequencial number
- Year of manufacture

**19 Characters :** 08 05 0013199 900640031

- Year of manufacture
- Month of manucfacture
- Product reference
- Sequencial number

**20 Characters :** 3675007 XX 2 07 070 00315

- Product reference
- Millenium of manufacture
- Sequencial number
- Manufacturing day
- Year of manufacture

**21 Characters :** 3675007 XX 07 070 0000315

- Product reference
- Year of manufacture
- Sequencial number
- Manufacturing day

The indications mentionned on the prices, commercial or technical literature and the scheme are written for your guidance and are available at a given time. The CONSTRUCTOR retains the power to modify the presentation, the form, the size, the conception or the material of the products.